

# KEVADURE

## WHEEL ASSEMBLY GUIDE

**1** | Unpack the container and lay out the wheel components—you should have 2 wheels and 4 screws.



**2** | Place your Evadure on a flat, stable surface. On the inside part of the frame you will be able to see the four mounting sections at each bottom corner.



**3** | Take one wheel and line it up with the corner bracket so the axle nub points inward. It should easily slot into place.



**4** | Grab two of the supplied screws and fasten the wheel to the slot using the pre-drilled holes on the wheel's metal bracket.



**5** | Repeat steps 3 and 4 for the remaining wheels, until all are attached.



**6** | Stand it upright, and the assembly process is now complete. Your Evadure is officially ready to roll.

