





01.

Open the bucket stopper and fill the water.
(There is a risk of frost in winter,
Use only 2/3 of water.)




02.

A pole is placed in the center of the bucket.




03.

After pushing the support into the holes
in the three corners of the bucket
Insert the step ring from the bottom.




04.

Four rings are inserted from the top
of the pole.




05.

Connect the crossbar to the top of the pole
and fill the stapling ring.




06.

The crossbar and the flag attached to the
pole attached to the pole
It will walk.



07.

The pole is a three-stage antenna type,
It is fixed by button.



08.

Finally, on the lower pole ring,
Adds weight to prevent flag curl.