

CONTENTS



1*TOP FRAME



1*BASE



1*MAIN FRAME



8*BANNER
SPRING HOOKS



2*BOLTS



1*HEX KEY

INSTRUCTIONS



Align the main frame with the base



Use the hex key to tighten the bolts



PLEASE NOTE THAT THE WATERBASE
NEEDS TO BE PURCHASED SEPARATELY